

INSTALLATION INSTRUCTIONS

GM DETENT CABLE END (UPPER)

Fits GM '76-Up; Taurus & Sable '86-up

 **NOTE:** Not recommended for 325, or 325-4L.

K35955CE

1. Push the old cracked or broken end toward the adjuster (Figure 1).
2. Press the cable through the slot on the face of the new cable end (Figure 2).
3. Slide the new cable end to cable stop, and reattach to carburetor (Figure 3).
4. Completed carburetor cable end replacement. Clips on in seconds (Figure 4).

