

# **INSTALLATION INSTRUCTIONS**

**Part# KT94125LB**

## **Cadillac Axle with Stabilizer**

**For GM 4T80E**

1. Remove the axle from the vehicle.
2. Remove the axle seal.
3. Clean the area where the seal was removed.
4. Place Blue Lock-Tite on the knurl and Blue Silicone on the corner/edge that will be against the case of the axle stabilizer.
5. Install the stabilizer until it bottoms against the case. You will know because the silicone will flatten against the case.
6. Install the new axle into the vehicle.
7. Test drive the vehicle and inspect to insure that there are no leaks.

**Teckpak Hotline: 1-800-527-2544**  
**[www.teckpak-fitzall.com](http://www.teckpak-fitzall.com)**