

INSTALLATION INSTRUCTIONS

Radiator Cooler Line "Repair" Fitting For FORD 1/2" Push-in Line ('02 & up)



Part# T16996ZR

1. Remove the old cooler line fitting - **ONE AT A TIME ONLY**. If you remove both fittings at the same time you will drop the inner cooler into the radiator.
2. Thread the new fitting into the radiator. **Do NOT use thread sealer or tape on the threads**. Torque fitting to 28 - 33 ft-lb.
3. Push the cooler line into the compression fitting until it bottoms and while holding it against the fitting tighten the compression nut until snug.
4. Place a wrench on the fitting to keep it from turning and finish tightening the compression nut.

